### **K2 Full Control Home**





Perfectly equipped for use on light dirt all around the home: the K2 Full Control Home power washer, includes a home kit with: patio cleaner T150 and 500 ml of Patio & Deck detergent, which enables the splash-free cleaning of larger areas such as a patio or decking. This pressure washer also comes with two smooth-running wheels, telescopic handle, a 4 m pressure hose, dirt blaster with rotating point jet for removing stubborn dirt and a water filter which protects the pump against dirt particles. In addition, the pressure settings SOFT, MEDIUM and HARD, as well as the detergent mode (MIX), can be set simply by turning the Full Control 4-Click Vario Power spray lance. The symbols indicate the ideal application areas for the pressure settings – for maximum control. This gives you the confidence to ensure you are using the correct pressure setting for the surface you are trying to clean. The power washer is ideal for dirt on bicycles, garden tools and garden furniture. Area performance of 20 m²/h. This machine comes with a 2 year manufacturer's guarantee.

MISSING PIC-TURE: D:\ IM0027641







#### **K2 Full Control Home**

- Full Control Click Vario Power spray lance with pressure setting display
- Extendable telescopic handle
- Spray lance storage

#### **Technical data** Order Number 1.673-405.0 EAN code 4054278246598 Pressure **bar / MPa** 20-110 / 2-11 Flow rate I/h 360 Max. water feed temperature °C max. 40 Power rating kW 1,4 Weight without accessories kg 4,3 246 × 280 × 586 Dimensions (L x W x H) mm Area performance m²/h 20

Equipment						
Home kit		T150 Patio Cleaner, Patio & Deck Detergent, 0.5 L				
High-pressure gun		G 120 Q				
Vario Power spray lance						
Dirt Blaster spray lance						
High-pressure hose	m	4				
Quick Connect on machine						
Detergent application via		Suction				
Integrated water filter						
Adapter garden hose A3/4"		I				
Click VPS						
The standard for staffaceure.						

■ Included in delivery.

# ACCESSORIES FOR K2 FULL CONTROL HOME 1.673-405.0































						_
		Order Number		Price	Description	
Hard surface cleaners			<u> </u>		<b>'</b>	t
PS 40 power swab surface cleaner	1	2.643-245.0			The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	_
T350 Patio Cleaner	2	2.643-252.0			The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	
Spare nozzles accesories	3	2.643-338.0				
Spare nozzles accesories T 300 / T	4	2.643-335.0				
350						Ľ
Brushes WB 150 power brush	5	2.643-237.0			The Kärcher WB150 pressure washer brush is the perfect	
WB 130 power brosii	J	2.043 237.0			attachment for cleaning delicate surfaces such as car exteri- ors, motorbikes, glass, garage doors and conservatories.	
WB100 Rotating Wash Brush	6	2.643-236.0			The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	
WB60 Soft Surface Wash Brush	7	2.643-233.0			The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	
Wheel Washing Brush	8	2.643-234.0			The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabiling you to reach every angle of your wheels.	
Washing brush rigid	9	6.903-276.0			Standard Kärcher brush for pressure washers. Perfect for removing stubborn dirt and cleaning a wide variety of firm surfaces, from cars and caravans to windows and garden	
Spray lances					furniture.	
Telescopic jet pipe	10	2.642-347.0			The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allwoing you to reach up to 4m.	) [
Splash guard	11	2.642-706.0			The transparent splash guard for K2 to K7 Kärcher pressure washers protects you and the surrounding area from spray water. Ideal for cleaning corners and edges.	
Angled spray lance	12	2.638-817.0			Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	
Single Lance Extension	13	2.643-240.0			Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	
Mini VP160 Vario Power Jet	14	2.643-254.0			The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K5 - K7 pressure washers.	
Full Control Dirt Blaster for K2 - K3, DB120	15	2.642-727.0			Dirt Blaster spray lance for K2 and K3 Kärcher pressure washers. This lance is perfect for tackling tough, stuck-on dirt like that on mossy or weathered surfaces.	
Special applications						
FJ 6 foam nozzle	16	2.643-147.0			The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	

## **ACCESSORIES FOR K2 FULL CONTROL HOME** 1.673-405.0



























		Order Number		Price	Description	
Foam nozzie Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	17	2.643-143.0			The Kärcher Ultra Foam Detergent & FJ10 C Connect ,n' Clean foam nozzle is the most effective way to apply detergent. Allowing you to switch between detergents for different tasks.	
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	18	2.643-144.0			Car Shampoo & FJ 10 C Connect ,n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Stone Clea- ner	19	2.643-145.0			3in1 Stone cleaner & FJ 10 C Connect ,n' Clean foam nozzle - The most effective way to apply deteregent. Also allows a simple switch between different detergents for different tasks.	
Roof gutter and pipe cleaning set	20	2.642-240.0			The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, downpipes and toilets. Compatible with all Kärcher pressure washers.	
Pipe cleaning set, 7.5 m	21	2.637-729.0			Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	
Pipe cleaning set, 15 m	22	2.637-767.0			Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	
Sand/wet blasting set	23	2.638-792.0			Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	
Vario joint	24	2.640-733.0			Vario joint, rotates 180° for cleaning difficult to reach areas Connection: For connection between gun and accessory or extension lance and accessory.	
Kärcher organiser	25	2.641-630.0			Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	
Chassis Cleaner	26	2.642-561.0			The Kärcher chassis cleaer is a highly effective underbody cleaner for the effortless removal of dirt, sludge, mud, sand and salt deposits from underneath your car.	
Accessory kits						
Bike Cleaning accessory kit	27	2.643-551.0			The bike cleaning accessory kit from Kärcher is the perfect addition to your pressure washer to help you clean your motor bike. This kit helo you achieve the perfect clean for your bike.	
Wood Cleaning Accessory Kit	28	2.643-553.0			Kārcher's wood cleaning accessory kit is perfect for cleaning all wooden surfaces. From garden furniture to decking, this accessory kit will help you achieve the perfect clean.	~ I
Car Cleaning Accessory Kit	29	2.643-554.0			The car cleaning accessory kit from Kârcher helps to transform your Kârcher pressure washer into the ultimate car cleaning tool. Including all the individual accessories you need for your car.	
Available accessories.						

# ACCESSORIES FOR K2 FULL CONTROL HOME 1.673-405.0































				1				
		Order Number					Price	Description
High Pressure Replacement Hose w	ith An	ti-Twist system a	nd Quick Connect	system				
H 10 Q PremiumFlex Anti-Twist	1	2.643-585.0						
High-pressure hose extension - Syst	tem fr	om 2009						
High-pressure replacement hose, 9	2	2.641-721.0						
m, K3 - K7								
High-pressure hose replacement kit				ı	ı			
HK 4 high pressure hose set *DE	3	2.643-912.0						
Adapter Set Extension Hose	4	2.643-037.0						
Miscellaneous				ı	ı			
G 160 Q	5	2.642-889.0						
Water filter	6	4.730-059.0						
Adapter for garden hose connection	7	2.640-732.0						
Replacement O-ring set	8	2.640-729.0						
Connectors/Tap adaptors								
Universal hose coupling with Aqua Stop	9	2.645-192.0						
Universal hose coupling	10	2.645-191.0						-  -
Hoses & Hose Reels/Trolleys								
Connection Set for high-pressure	11	2.645-156.0						
cleaners								
Indoor Hose Connection Set	12	2.645-258.0						
PrimoFlex® Hose: 20m	13	2.645-138.0						
Premium Hose Reel HR 7.315 Kit 1/2"	14	2.645-164.0						
□ Available accessories								

<sup>☐</sup> Available accessories.