



Einhell

EXPERT PLUS

POWER X-CHANGE

GE-CH 1846 Li Kit (1x2,0Ah)

Cordless Hedge Trimmer

Item No.: 3410683

Ident No.: 11027

Bar Code: 4006825615432

The GE-CH 1846 Li Kit cordless hedge trimmer is an efficient tool which thanks to its low weight and handy size provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. With the new Power X-Change battery system from Einhell, the hedge trimmer has an 18 V battery pack with 2.0 Ah for long work sessions.

Features

- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- Small and easy to handle
- Low weight for user-friendly operation
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover on cutters
- Bumper guard with holder for wall mount
- Blades made of laser-cut and diamond-ground steel
- Sturdy cutter guard for storage and transportation





Technical Data

- | | |
|--------------------------|--------------------------|
| - Max. running time | 80 min |
| - Charging time | 40min |
| - Blade length | 520 mm |
| - Cutting length | 460 mm |
| - Spacing between teeth | 15 mm |
| - Cuts per minute | 2200 min ⁻¹ |
| - Accumulator | 18 V 2000 mAh Li-Ion |
| - Number of accumulators | 1 Pieces |

Logistic Data

- | | |
|---------------------------------|--------|
| - Product weight | 2.3 |
| - Gross weight single packaging | 3.4 kg |
| - Product weight | 2.3 kg |



Available as special accessories



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory