




K 4 Premium Full Control Home

The K 4 Premium Full Control Home comes with a five year warranty. The addition of a hose reel and the home kit make cleaning around your home easier than ever.

MISSING
PIC-
TURE: D:\
IM0027641



1 Full Control trigger gun and spray lances

- Gives you direct feedback as to the pressure setting you are on, ensuring you get the right pressure setting for the surface you are trying to clean.
- The pressure can be regulated by twisting the Vario Power spray lance until the desired level is shown.



2 Hose reel

- The high-pressure hose can be quickly and easily wound onto the hose reel, helping provide a simple storage solution.



3 Plug and Clean

- Quick and easy application of detergents through the pressure washer, when in detergent mode.
- The Plug and Clean detergent can be replaced quickly and easily with one simple movement.



4 Telescopic handle

- For a convenient pulling height.
- Completely retractable for a compact storage solution.



K 4 Premium Full Control Home

- Full Control Trigger Gun with pressure setting display
- Maximum stability thanks to low centre of gravity, hose guide and a larger base
- Highly efficient water-cooled motor

Technical data

Order Number		1.324-105.0
EAN code		4054278130835
Pressure	bar / MPa	20-130 / 2-13
Flow rate	l/h	420
Max. water feed temperature	°C	40
Power rating	kW	1,8
Weight without accessories	kg	11,9
Dimensions (L x W x H)	mm	411 x 305 x 584
Current type	V / Hz	230 / 50

Equipment

Home kit	T350 Patio Cleaner, 1 L 3-in-1 Stone and Facade Detergent	Adapter garden hose A3/4"	■
High-pressure gun	G 145 Q Full Control		
Vario Power spray lance	■		
Dirt Blaster spray lance	■		
High-pressure hose reel	■		
High-pressure hose	m	6	
Detergent application via	Plug and Clean system		
Telescopic handle	■		
Water-cooled motor	■		
Soft bag	■		
Integrated water filter	■		

■ Included in delivery.

ACCESSORIES FOR K 4 PREMIUM FULL CONTROL HOME **KÄRCHER**

1.324-105.0



		Order Number						Price	Description	
Hard surface cleaners										
T350 Patio Cleaner	1	2.643-252.0							The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	■
PS 40 Power Scrubber	2	2.643-245.0							The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	□
T450 Patio Cleaner	3	2.643-214.0							The T450 Kärcher patio cleaner is a handy attachment for your Kärcher pressure washer. Twin-jet rotating arms allow you to clean areas like patios and decking faster and with great results.	□
Spare nozzles accessories	4	2.643-338.0							High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.	□
Spare nozzles accessories T 300 / T 350	5	2.643-335.0								□
T550 Patio Cleaner	6	2.643-251.0							The Kärcher T550 patio cleaner is our most powerful patio cleaner. Allowing you to clean large surface areas quickly. Included in this model is a detergent application feature.	□
Spray lances										
Full Control Vario Power Jet for K4 - K5, VP145	7	2.642-725.0							This spray lance is continuously adjustable from low-pressure detergent jet to high-pressure jet, simply by turning the spray lance. Suitable for use with K4 - K5 power washers.	■
Full Control Dirt Blaster for K4 - K5, DB145	8	2.642-728.0							The Dirt Blaster for power washers in the K4 - K5 range. This spray lance is suitable for use on particularly stubborn dirt like mossy pavements or house walls.	■
Splash guard	9	2.642-706.0							The transparent splash guard for K2 to K7 Kärcher pressure washers protects you and the surrounding area from spray water. Ideal for cleaning corners and edges.	□
Angled spray lance	10	2.638-817.0							Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle under-bodies.	□
Single Lance Extension	11	2.643-240.0							Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	□
Mini VP160 Vario Power Jet	12	2.643-254.0							The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K2 - K7 pressure washers.	□
MP 145 Multi Power Jet	13	2.643-239.0							The Kärcher multi-power jet has 5 different types of jets: Cleaning agent jet, High Pressure fan jet, rotary nozzle, pencil jet and wide reduced-pressure fan jet.	□
Telescopic jet pipe	14	2.642-347.0							The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allowing you to reach up to 4m.	□
Miscellaneous										
Full Control Trigger Gun	15	2.643-634.0							New Full Control trigger gun comes with an LED display to guide you to the correct pressure setting for the surface you are trying to clean. Helping you achieve the best results for your home.	■

■ Included in delivery. □ Available accessories.

ACCESSORIES FOR K 4 PREMIUM FULL CONTROL HOME **KÄRCHER**

1.324-105.0



		Order Number						Price	Description	
Water filter	16	4.730-059.0							Water filter protects pressure washer pumps against dirt particles from dirty water.	<input type="checkbox"/>
Replacement O-ring set	17	2.640-729.0								<input type="checkbox"/>
Adapter for garden hose connection	18	2.640-732.0								<input type="checkbox"/>
Brushes										
WB 150 power brush	19	2.643-237.0							The Kärcher WB150 pressure washer brush is the perfect attachment for cleaning delicate surfaces such as car exteriors, motorbikes, glass, garage doors and conservatories.	<input type="checkbox"/>
WB100 Rotating Wash Brush	20	2.643-236.0							The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	<input type="checkbox"/>
WB60 Soft Surface Wash Brush	21	2.643-233.0							The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	<input type="checkbox"/>
Wheel Washing Brush	22	2.643-234.0							The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabling you to reach every angle of your wheels.	<input type="checkbox"/>
High-pressure hose extension - System from 2009										
H10 Q High-Pressure Hose for Hose Reel Machines	23	2.643-633.0							This 10m high-pressure hose replacement can be connected to all K4 to K7 Kärcher pressure washers with a hose reel.	<input type="checkbox"/>
High-pressure hose extension - System from 2008										
High-pressure extension hose, 10 m, K2 - K7 (for gun model "Best").	24	2.641-710.0							High-pressure extension hose for greater flexibility. 10 m robust DN 8 quality hose for durability. For K2 - K7 series from 2008 with Quick Connect connector.	<input type="checkbox"/>
High-pressure extension hose, 10m	25	2.641-708.0							The Kärcher high-pressure extension hose gives you greater flexibility. The 10m high-quality hose is steel reinforced for durability. Compatible with K3 - K7 pressure washers.	<input type="checkbox"/>
High-pressure extension hose, 6 m, K3 - K7 (for gun model "Best").	26	2.641-709.0							High-pressure extension hose for greater flexibility. 6 m robust DN 8 quality hose for durability. For K3 - K7 series from 2008 with Quick Connect connector.	<input type="checkbox"/>
Special applications										
FJ 6 foam nozzle	27	2.643-147.0							The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	<input type="checkbox"/>
Pipe cleaning set, 7.5 m	28	2.637-729.0							Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Pipe cleaning set, 15 m	29	2.637-767.0							Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Vario joint	30	2.640-733.0							Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.	<input type="checkbox"/>
Kärcher organiser	31	2.641-630.0							Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	<input type="checkbox"/>
Suction hose SH 5	32	2.643-100.0							Eco-friendly 5 metre suction hose for drawing water from alternative sources such as water butts and barrels.	<input type="checkbox"/>
Foam nozzle Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	33	2.643-143.0							The Kärcher Ultra Foam Detergent & FJ10 C Connect 'n' Clean foam nozzle is the most effective way to apply detergent. Allowing you to switch between detergents for different tasks.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

ACCESSORIES FOR K 4 PREMIUM FULL CONTROL HOME **KÄRCHER**

1.324-105.0



		Order Number					Price	Description	
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	34	2.643-144.0						Car Shampoo & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	<input type="checkbox"/>
Roof gutter and pipe cleaning set	35	2.642-240.0						The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, down-pipes and toilets. Compatible with all Kärcher pressure washers.	<input type="checkbox"/>
Sand/wet blasting set	36	2.638-792.0						Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	<input type="checkbox"/>
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Stone Cleaner	37	2.643-145.0						3in1 Stone cleaner & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

ACCESSORIES FOR K 4 PREMIUM FULL CONTROL HOME **KÄRCHER**

1.324-105.0



		Order Number						Price	Description	
Connectors/Tap adaptors										
Universal hose coupling with Aqua Stop	1	2.645-192.0							Universal hose coupling with Aqua Stop. Ergonomic design for convenient handling.	<input type="checkbox"/>
Universal hose coupling	2	2.645-191.0							Our universal hose coupling is an essential part of the Kärcher garden irrigation system, extending the length of your hose to make sure every inch of your garden gets the care it deserves.	<input type="checkbox"/>
Hoses										
Connection Set for high-pressure cleaners	3	2.645-156.0							Hose set for high pressure cleaning or for watering the garden. With 10 m PrimoFlex®-hose (3/4"), G3/4-tap adapter, 1 x Universal hose connector as well as Universal hose connector with Aqua Stop.	<input type="checkbox"/>
Indoor Hose Connection Set	4	2.645-258.0							This indoor hose connection set provides the perfect solution if you need to connect your power washer to an indoor tap.	<input type="checkbox"/>
PrimoFlex® Hose: 1/2" - 20m	5	2.645-138.0							This PrimoFlex® hose is durable, with a woven reinforced garden hose with pressure resistant features and operating temperature range from -20 to 65°C, making it ideal for gardening.	<input type="checkbox"/>
Hose Storage and Hose Trolley										
Premium Hose Reel HR 7.315 Kit 1/2"	6	2.645-164.0							Watering Station for the practical and space-saving stowage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.