

ROTARY ATTACHMENTS

Detailer's Grip

(A577 / Part No. 2615A577AA)

Contents: Detailer's Grip Attachment.

Offers enhanced grip and comfort for detailed applications.



Mini Saw Attachment

(670 / Part No. 26150670AC)

Contents: Mini Saw Attachment, Rip/Cross-Cut Blade (546), Driver Cap.

Transforms your Dremel® tool into a precision circular saw for fine, clear and straight cuts in all sorts of wood.



Sharpening Kit

(A679-02 / Part No. 26150679AD)

Contents: Garden Tool Sharpening Attachment, Lawn Mower Sharpening Attachment, Sharpening Stones (453, 454, 455, 932).

Ideal for sharpening blades.



Multi-Vise™

(2500-01 / Part No. 26152500JB)

Contents: Dremel® Multi-Vise™, Removable Soft-Pads, Tool Holder Adapter.

Rotates 360° and tilts 50° allowing the user to lock the workpiece in any position. Clamps to any workbench, table or countertop.



Circle Cutter & Straight Edge Guide

(678-01 / Part No. 26150678AE)

Contents: Circle Cutter Attachment and Straight Edge Guide.

Makes circles from 1.9-30 cm and the Straight Edge Guide allows routing or cutting in a straight line.

