

Magnifying Lamp

DURATOOL


Features

- Ideal for engineers to view micro components or PCB, or medical person or beautician to light or magnify.
- Integration of magnifying and lighting.
- Bright and stable light, no flash feeling, no harm to eyesight.
- Supplied with electronic ballast.

Specifications

Lens size	: 5 inch
Lens material	: Glass
Diopter	: 5D
Light Sources	: 80pcs LED 15W
Standard Mount	: Table Base

Operation Instructions

- Take the lamp out of the packaging and place it on a level, even surface.
- Adjust the lamp holder and the light-arm as desired.
- Switching on the LED magnifying lamp, then start your operation.

Important for safe use

- Indoor use only.
- Environment temperature: -20°C to +40°C
- Humidity: ≤95%

Attention

- The product can only be used indoors, never outdoors. Do not expose to moisture, under any circumstances.
- Do not look directly into the light source, when the lamp is in operation.
- Never look into light sources, such as LED lamps or lasers, through the magnifying glass. This may result in eye injuries, due to the optical interaction.
- Always cover the magnifying glass with the plastic cover when it's not in use, otherwise there is a risk of fire due to the burning glass effect in direct sunshine.

DURATOOL

Magnifying Lamp



- Never leave the lamp without supervision when it is in use.
- Check the lamp for damage from time to time. Don't touch the device if the lamp or the mains adaptors show any signs of damage. Please switch off the appropriate mains socket and then carefully pull the mains plug from the socket then take it to a specialist workshop.

Maintenance

- Remove loose particles with clean compressed air and then brush off remaining residues with a soft fine brush.
- Clean the surface with a lens cleaning cloth or a clean, soft and lint-free cloth. To remove fingerprints and other fat residues, the cloth can be moistened with water or lens cleaning solution.
- Do not use acid, alcohol or other solvents or rough, fuzzy cloths. Avoid excessive cleaning and exerting too much pressure.
- Never touch the lens with your fingernails or other sharp objects.

Part Number Table

Description	Part Number
Magnifying Lamp	DT000089

