0 603 3C9 070 - EasyCut 12

Material number	0 603 3C9 070
EAN	3165140830843
1 battery pack PBA 12V 2.5Ah O-B	\checkmark
Charger AL 1115 CV	\checkmark
Plastic case	\checkmark
Storage loop	\checkmark
Transparent saw blade protective cover 1 600 A00 J6Z	\checkmark
nanoBLADE Wood Speed 65 2 609 256 D86	\checkmark

Technical data

Description

Product name (formatted)

Technical data

Battery voltage	12,0 V
Battery capacity	2,5 Ah
No-load speed	0 – 4.100 rpm
Sole plate	Steel
Machine weight	0,9 kg

EasyCut 12





Cutting depth

Cutting depth in wood	65 mm
Cutting depth in plastic	30 mm

Functions

12 Volt	1
Lithium-ion technology	\checkmark
Bosch SDS	\checkmark
Bosch Low Vibration	\checkmark
Bosch Electronic	\checkmark
Softgrip	\checkmark
Bosch Electronic Cell Protection (ECP)	1

Noise/vibration information

Sound pressure level	75 dB(A)
Sound power level	86 dB(A)
Uncertainty K	3 dB



Sales information

Positioning

Freehand cuts easier than ever before

User benefit

- The NanoBlade technology now allows freehand cuts even without clamping the workpiece
- Versatile sawing both inside and outside the house
- Easily performing quick and straight cuts

Other features

- Sawing close to edges thanks to the new design, e.g. to cleanly cut off branches close to the trunk
- Easy, safe and quick saw blade change by simply opening the hatch, changing the saw blade and closing the hatch
- The new sawing technology is absolutely maintenance-free, requiring no oiling or sharpening of the saw blade
- The lithium-ion battery ensures that the saw is ready to use any time and anywhere. The battery is changeable, enabling it to be used in other tools in the Power for ALL System
- Bosch Electronic for fingertip control when starting to saw
- An attached storage loop can be used to hang up the tool on a branch or a ladder string during work